

# SV1simc Manual

Concurrent Dynamics International

May 2014

# Objectives

- Part I:
  - Build a model file (SV1simc.txt) to simulate a satellite with 4 reaction wheels and 8 jets
  - Build simplot1.m to view sim results
- Part II:
  - Build control.dll to interact with the main program xsv01.exe during run time to simulate the dynamics and control of the SV1simc vehicle.
  - Xsv01.exe Examples:
    - use reaction wheels to maintain LVLH attitude with jets idled
    - use reaction jets and wheels to maintain LVLH attitude

# License Restrictions


License type	Buildx.exe	Xsv01.dll
Enterprise	none	none
Project	Must stay with the object count specified by license gflag <=12	Runs with model_files with license specified object count gflag <=12

- Project license permits satellite simulations of satellites with a specified object count in {bodies, wheels, forces} and in a unique configuration. No restrictions are placed on the mass property of bodies and wheels, and force placement and parameters or initial conditions.
- Project license permits gravity model with gflag <=12 (see page 35)

# Part I Buildx Topics

- Physical model
- Buildx tasks
- Key files
- Main Menu
- Model Menus
- Model Items
- Body Menu
- B1 page
- Body Actuation Signals
- Wheel menu
- Force menu
- Gravity Menu
- Dynamics Input
- Dynamics Output
- Plot Data
- Simplot
- Save Model
- Exit Buildx
- Q & A

# SV1simc Model



reaction wheels axes on b1:

$$w1 = [1 \ -1 \ 1] / \sqrt{3}$$

$$w2 = [1 \ 1 \ 1] / \sqrt{3}$$

$$w3 = [-1 \ 1 \ 1] / \sqrt{3}$$

$$w4 = [-1 \ -1 \ 1] / \sqrt{3}$$

jet forces on b1:

$$f1.pos = [-3 \ 3 \ 0], \ f1.vec = [1 \ 0 \ 0]$$

$$f2.pos = [-3 \ -3 \ 0], \ f2.vec = [1 \ 0 \ 0]$$

$$f3.pos = [-3 \ 0 \ 3], \ f3.vec = [1 \ 0 \ 0]$$

$$f4.pos = [-3 \ 0 \ -3], \ f4.vec = [1 \ 0 \ 0]$$

$$f5.pos = [0 \ 3 \ 3], \ f5.vec = [0 \ -1 \ 0]$$

$$f6.pos = [0 \ 3 \ -3], \ f6.vec = [0 \ -1 \ 0]$$

$$f7.pos = [0 \ 0 \ 0], \ f7.vec = [0 \ 0 \ 0]$$

$$f8.pos = [0 \ 0 \ 0], \ f8.vec = [0 \ 0 \ 0]$$

# On the Simulation

- We build a model file in Part I to simulate the dynamics and control of a vehicle in orbital environment. The model file defines the mass property of the vehicle and reaction wheels. It also defines jet forces, vehicle's initial orbit motion and the dynamics input and output signals for the control system.
- Part II presents the procedure to generate the control.dll required by xsv01.exe for the simulation. Examples are then presented to run xsv01.exe with control.dll to simulate the control/dynamics as specified by sv1simc.txt

# Buildx Tasks

- Build a [model file](#) to define a satellite simulation:
  - {mass property,model connectivity, degree of freedom,xsv01.dll input/output,plot data,gravity model,...etc}
- Build control.cpp template for SV1simc control system
- Edit & browse the attributes of satellite components
  - {bodies,wheels,forces,markers,gravity,initial state,...}
- Build a Matlab plot script, simplot1.m, to view sim results


# Key Files in c:\SV1simc

- Buildx.bat='..\Buildx'
- Input files router: siminput.txt
- Working files: sim1files.txt
- Simplot text: i.e. simplot1.txt
- License: simlicense.txt



# Starting Buildx.exe

- Click c:\SV1simc\Buildx.bat to start Buildx.exe and see the Main Menu



# Main Menu

- Shows all working files and timing data defined in the simInputFile

```
*****
*          BBBB U U I L DDDD X X          *
*          B B U U I L D D X X          *
*          BBBB U U I L D D X          *
*          B B U U I L D D X X          *
*          BBBB   UU I LLL DDDD X X          *
*          ~~~~~~                          *
*                   xsv version 1.0          *
*                   copyright 2014          *
*                   concurrent dynamics international *
*          *****                          *

simInputFile: simfiles.txt          < ENTERPRISE

Model file < svlsimc.txt

Plot file > z.1
Summary file > sim1_summary.txt
Message file > sim1_message.txt

stepSize      = .100000E-01; plotDt      = .200000E+01
simEndTime    = .300000E+04; printDt     = .500000E+02
simMethod     = RK2

commands:
[ xsv          openI   saveI   openM   saveM   ]
[ message model flex   plot   summary switch ]
[ stepSize plotDt printDt endTime method reset ]
[ help        x       ]
>
```

- Type 'xsv' to go to Model Menus

# Model Menu

- See model parts size or to choose menus to edit/browse

```
System Graph:
b1(B)+-w[1,2,3,4]

total bodies:          5      ; reg. bodies& wheels:    1,  4
ext. forces,torque:   8,  0  ; pos.& dir markers:    0,  0
system units:        FPS    ; constraints:         0
sysAcc flag:         1      ; input (param,size): 10, 10
gravity flag:        10     ; output(parmm,size):  2,  6
accels,gyros:        0,  3  ; plot (parmm,size): 16, 34
ode & switches:      0,  0  ; discrete procs:      2
ode states:          0      ; System states:      20
vmass,pmass:         0,  0

License: ENTERPRISE

[body  force  torque  pmkr  dmkr  input  output  plot      ]
[simplot flex  jnt  cnx  wheel  accel  gyro   grav   sunPos   ]
[sep   vmass  pmass  discr  ode   switch  states  sumry  units]
[times  compute  cn   tree(f/t/p/d)  cgen  help   save   x     ]
> _
```

- SV1simc has 1 regular body, 4 wheels and 8 forces

# Sv1simc Model Items

Defined Items	Menu	Parameters/data
1 body	Body	Mass, inr, svec,dvec, dcm0, axis,ang,wrel,parent,type
4 wheels	Wheel	Winr, axis, wspd, parent, type
8 forces	Force	Fvec,fpos, parent,type
Plant input	Input	Xv01.dll input data list
Plant output	Output	Xsv01.dll output data list
Plot data	Plot	Xsv01.dll plot data list
Orbit	Gravity	Vehicle's orbit position and velocity

- Attributes of the defined items can be seen by going to the Menus specified above. Use the Model Menu commands to do that.
- Part I gives the instructions on how to define the above parameters and data
- If already familiar with Part I, go to Part II on page 50

# Model Menu Commands

- Type 'body' to go to Body Menu
- Type 'force' to go to Force Menu
- Type 'grav' to go to Gravity Menu
- Type 'pmkr' to go to Position Marker Menu
- Type 'dmkr' to go to Direction Marker Menu
- Type 'input' to go to Input Menu
- Type 'output' to go to Output Menu
- Type 'plot' to go to Plot Menu
- Type 'simplot' to go to SimPlot Menu
- Type 'time' to go to Timing Menu
- Type 'help' to get definition on data and commands
- Type 'x' to exit menu

# Body Menu

- See body summary, type 'body' from Model Menu
- SV1simc has 1 body, i.e. b1

```
~ Body Menu ~
no. of bodies : 1
sysh_eci      :      2.094      10.966      -1.262
sysh_b1      :      3.491      10.472      -2.094
syscm       :      .000      .000      .000

dvec =      .000      .000      .000
svec =      .000      .000      .000
hpos =      .000      .000      .000
rpos =      .000      .000      .000
wrel =      .200      .500      -.100
inr  = 1000.000 1200.000 1200.000
      .0000   .0000   .0000

idx name      pa u fl vm tp ax -- angle -- -- mass --
=> 1 b1      0 FPS 0 - B x      .000 100.000

[ sel edit  idx  name  par  dvec  svec  type  whl  units ]
[ axis ang  dpos  wrel  dvel  inr   mass  hpos  hvel  rpos ]
[ add addF  cnx   jnt   rem   dmkr  pmkr  gvec  rvel  w   l ]
[ brch cn   copy  up    down  doIc  save  help  zero  x   l ]
> _
```

# Body Menu Data & Commands

- Sysheci system angular momentum in ECI frame
- Syshb1 sysheci in b1 frame
- Syscm system cm in b1 frame
- Dvec-inr position, rate and inertia of the body pointed by '=>' arrow
- Column data
- Pa parent body index
- U units of measure {FPS=English, MKS=Metric}
- Tp joint type {a-h}
- Ax local axis for 1 dof joints {x, y or z}
- Ang initial joint angle (deg)
- Mass body mass

- Body Menu Commands:
- Type 'add<j>' to add bodies to bj : i.e. 'add1' to add bodies to b1
- Type 'rem<j>' to remove bj from list
- Type 'name<j>' to edit bj.name
- Type 'par<j>' to edit bj.parent
- Type 'type<j>' to edit motion type, bj.type: {a...h}
- Type 'axis<j>' to edit bj.axis: {x, y or z}
- Type 'ang<j>' to edit initial inboard bj.ang for 1 dof rotational joints
- Type 'wrel<j>' to edit bj.angular\_rate
- Type 'mass<j>' to edit bj.mass
- Type 'svec<j>' to edit bj.svec
- Type 'dvec<j>' to edit bj.dvec
- Type 'inr<j>' to edit bj.inr
- Type 'edit<j>' to see all data on bj
- Type 'help' to get definition on data and commands
- Type 'x' to exit menu



# 3 Ways to Edit Body Data

- Direct edit: type the following commands for immediate edit
  - name<j>, type<j> axis<j>, ang<j>, mass<j>
  - units<j>
  - i.e. 'name1' to change b1 name
- Parameter menu edit: type any of the following parameters and go to named menu and then edit
  - {dvec, svec, inr, wrel, dpos, dvel, ... }
- Selected body edit: Type 'edit<j>' to edit all parameters of bj

# Inertia Menu

- Need define moi of each body bj about the bj.cm
- Type 'inr' from Body Menu to see a summary of moi data

```
idx name  -   ixx  - -   iyy  - -   izz  -  
          ----  ixy  ---  ----  ixz  ---  ----  iyz  ---  
=>  1  h1      .1000000E+04  .1200000E+04  .1200000E+04  
          .0000000E+00  .0000000E+00  .0000000E+00
```

- Type 'inr<j>' to edit bj.inr
- Type 'x' to exit menu

# Dvec Menu

- Need define dvec(j), bj.hinge.position in bj.parent frame, for each j
- Type 'dvec' from Body Menu and see a dvec summary

```
idx name          u -----dvec-----  
=>  1  b1          FPS  .0000000E+00  .0000000E+00  .0000000E+00
```

- note: by design b1.dvec=0
- Type 'dvec<j>' to edit bj.dvec
- Type 'x' to exit menu

# Svec Menu

- Need define svec(j), bj.position.cm in bj.local frame, for each j
- Type 'svec' from Body Menu and see an svec summary

```
  idx name      u -----svec-----  
=>  1 b1      FPS  .0000000E+00  .0000000E+00  .0000000E+00
```

- note: b1.cm here is collocated with b1.hinge point, but can be nonzero
- Type 'svec<j>' to edit bj.svec
- Type 'x' to exit menu

# Pos Summary

- See where `bj.cm` is in `b1` frame for all `j`
- Type 'rpos' in Body Menu to see a summary of `bj.cm`

```
idx name      ----- rpos -----  
=>  1 b1          .000          .000          .000
```

- note: `b1.cm` here is collocated with `b1.hinge` point but need not be so

# All b1 Data

- See all data on b1, type 'edit1' from Body Menu

idx	name	par	gflg	u	tp	ax	ang	mass
1	b1	0	10	FPS	b	x	.000	.10000E+03
>	inertia<inr>=	.10000E+04			.12000E+04		.12000E+04	
		.00000E+00			.00000E+00		.00000E+00	
>	dVec	=	.000		.000		.000	
	hngVec	=	.000		.000		.000	
>	sVec	=	.000		.000		.000	
	rVec	=	.000		.000		.000	
>	dcm0	=	1.000000		.000000		.000000	
			.000000		1.000000		.000000	
			.000000		.000000		1.000000	
	Euler seq	=123						
	Euler angs	=	.000		.000		.000	
	b2i matrix	=	-.000002		.000000		-1.000000	
			.422618		.906308		-.000001	
			.906308		-.422618		-.000002	
>	wRel	=	.2000		.5000		-.1000	
>	dPos	=	.000		.000		.000	
>	dVel	=	.000		.000		.000	
	force on b	=	.000		.000		.000	
	torque on b	=	.000		.000		.000	

# Bj Page Info

- 1<sup>st</sup> block: all attributes of bj, {idx, ... torque on b}
- 2<sup>nd</sup> block: commands to change attributes in block1 or to go to another Body Menu: {idx, axis,... x}
  - idx<j>: goes to another bj page
  - dcm0: edit relative dcm of bj
    - for j=1, this is the b1 attitude wrt LVLH frame
  - svec: edit the bj cm position in bj coord, etc...
  - help: see data and command definitions
  - x: exit this page

# Body Actuation Signals

- B<sub>j</sub> Inboard force or torque actuates that body and impacts the motion of the rest of the system. Accelerations can be specified for joints with prescribed motion
- The Dynamics Input signals for b<sub>j</sub> depends on b<sub>j</sub>.type. They are processed as follows:

type	Size	Input	processing
A	1	Htqax,j	bj.torque(axis)=Htqaxj
B	3	Htq,j	bj.torque=Htqj
C	1	Wraccax,j	bj.wracc(axis)=Wraccaxj
D	3	Wracc,j	bj.wracc=wraccj
E	1	Frcax,j	bj.force(axis)=frcaxj
F	3	Frc,j	bj.force=frcj
G	1	Hraccax,j	bj.hraccax=hraccaxj
H	3	Hracc,j	bj.hracc=hraccj



# Wheel Menu

- See wheel summary, type 'whl' from Model Menu
- SV1simc has 4 wheels all mounted on b1 (see pa)

```
~ Wheel Menu ~
nof wheels      :      4
Sysh_eci        :      1.52      1.54      -.43
SysCm           :      .000      .000      .000

w_inr           :      .10000
w_spd(rpm)     :      .000
w_mom          :      .000

az_axis         :      2
axis(1) az(d)  :      45.000000
axis(1) el(d)  :     -35.264390

units           :  FPS

idx name      pa t ----- ---axis--- ----- --winr-- -w(rpm)-
=>  1 whl1     1 A   .577350  -.577350  .577350  .1000  .0
    2 whl2     1 A   .577350  .577350  .577350  .1000  .0
    3 whl3     1 A  -.577350  .577350  .577350  .1000  .0
    4 whl4     1 A  -.577350  -.577350  .577350  .1000  .0

[ sel name units par type  inr  wspd  axis  azel azAxis long ]
[ show order  idx  add  rem  copy  save  help  x      ]
>
```

# Wheel Menu Data & Commands

- Data:
  - `whlj.parent= 1`, for all `j`, means all wheels are on `b1`
  - `whlj.type=A` means `whlj.input` is scalar wheel torque
  - `whlj.axis= [x y z]` , `whlj` spin axis in parent frame
  - `whlj.speed=` initial `whlj` speed
  - `whlj.inr=whlj` spin axis inertia
- Commands:
  - Type `'add<j>'` to add wheels to `bj`
  - Type `'rem<j>'` to remove `whlj`
  - Type `'name<j>'` to edit `whlj.name`
  - Type `'type<j>'` to edit `whlj.type={A or C}`
  - Type `'axis<j>'` to edit `whlj.axis`
  - Type `'wspd<j>'` to edit `whlj.wspd`
  - Type `'help'` to get definitions of data and commands
  - Type `'x'` to exit menu

# Wheel Control Signals

- Dynamics Input signals for whlj: whltqj, whlaccj
- Run time input processing of wheel control signals:

whlj.type	Input signal	size	Sim action
A	whltqj	1	whlj.tq= whltqj
C	whlaccj	1	whlj.acc= whlaccj

# Force Menu

- See force summary, type 'force' from Model Menus
- SV1simc has 8 jet forces
- fj.parent=1 for all j, means they all impinge b1
- fj.type=1 for all j means that the xsv01.dll input for them are 1/0 signals

```
idx name      p t  c  ---f mag---  ----fx----  ----fy----  ----fz----
=>  1 f1        1 1  1    1.000    1.000    .000    .000
    2 f2        1 1  1    1.000    1.000    .000    .000
    3 f3        1 1  1    1.000    1.000    .000    .000
    4 f4        1 1  1    1.000    1.000    .000    .000
    5 f5        1 1  1    1.000    .000    -1.000    .000
    6 f6        1 1  1    1.000    .000    -1.000    .000
    7 f7        1 1  1    .000    .000    .000    .000
    8 f8        1 1  1    .000    .000    .000    .000
```

- note: f7,f8 are not given force values because they are not needed by acs\_jet.m of SV1simc1

- Type 'pos' to see the position of defined forces in b1 coord as next

```

=>  idx name      p t c  ---f mag---  ---posx---  ---posy---  ---posz---
      1 f1        1 1 1    1.000    -3.000    -3.000     .000
      2 f2        1 1 1    1.000    -3.000     3.000     .000
      3 f3        1 1 1    1.000    -3.000     .000      3.000
      4 f4        1 1 1    1.000    -3.000     .000     -3.000
      5 f5        1 1 1    1.000     .000     3.000     3.000
      6 f6        1 1 1    1.000     .000     3.000    -3.000
      7 f7        1 1 1     .000     .000     .000     .000
      8 f8        1 1 1     .000     .000     .000     .000

```

- Type 'rx' to see the torque of defined forces in b1 coord

```

=>  idx name      ---tqmag---  ---tqx---  ---tqy---  ---tqz---
      1 f1        3.000     .000     .000     3.000
      2 f2        3.000     .000     .000    -3.000
      3 f3        3.000     .000     3.000     .000
      4 f4        3.000     .000    -3.000     .000
      5 f5        3.000     3.000     .000     .000
      6 f6        3.000    -3.000     .000     .000
      7 f7        .000     .000     .000     .000
      8 f8        .000     .000     .000     .000

```

# Force Menu Data & Commands

- Data:
  - `fj.parent= 1`, for all `j`, means all jets are on `b1` (bus)
  - `fj.type=1` means `fj.input` is an on/off signal
  - `fj.fvec= [x y z]` ,directional vector of `fj`
  - `fj.fmag=` magnitude of `fj` when activated
  - `fj.fpos=[x y z]`, impact position of `fj` in parent frame
  
- Commands:
  - Type '`add<j>`' to add external forces to `bj`
  - Type '`rem<j>`' to remove `fj`
  - Type '`name<j>`' to edit `fj.name`
  - Type '`type<j>`' to edit `fj.type={1,2 or 3}`
  - Type '`fvec<j>`' to edit `fj.fvec`
  - Type '`fpos<j>`' to edit `fj.fpos`

- Type 'par<j>' to edit fj.parent
  - Type 'pos' to show all force impact positions in b1 frame
  - Type 'rx' to show torque of all forces about f\_ref in b1 frame
  - Type 'help' to get definitions of data and commands
  - Type 'x' to exit menu
- Dynamics Input signal for fj is x fj

### Run time input processing of x fj:

fj.type	x fj	Size	Sim Action
1	1=on, 0=off	1	fj.force= x fj*fj.fvec
2	Scalar magnitude of fj.force	1	fj.force= x fj*fj.unitv
3	3 x 1 force vector in b1 frame	3	fj.force= x fj

# Gravity/Orbit Menu

- Need to specify the vehicle orbit
- Type 'grav' from Model Menu to enter Gravity Menu
- SV1simc orbit :
  - 35 deg inclined circular orbit
  - True anomaly= 90 deg
  - orbit period is 100 minutes
  - gflag= 10, meaning spherical earth gravity model
  - epoch: 12.23.2009 (see sunpos menu) relates to LST



# Gravity Menu

```
> units      (U)=  FPS
> syspos    =      37130491.887      27.245      58.427
> sysvel    =      -.034      8232.778      17655.249

> refpos    =      37130491.887      27.245      58.427
> refvel    =      -.034      8232.778      17655.249

gravity:
> gx gy gz  = -10.2101349554    -.0000074919    -.0000160664
mu          = .140764418E+17

ephemeris:
> semimajor (U)=      37167659.547
> ecc        =      .001000
> incl      (deg)=      65.000000
> rasc      (deg)=      .000000
> argp      (deg)=      .000000
> t_anom    (deg)=      .000099
e_anom     (deg)=      .000099
m_anom     (deg)=      .000099
m_motion(d/s)= .03000000

> LST_ang (deg)= 268.291360
> LST(h:m:s) = 17:53: 9.9

> period (min)=      200.000; revs/day=      7.200
> period (sec)=      12000.000
range      (U)=      37130491.887
equ. radius =      20925646.325; J2= .108263E-02
prg.altitude =      16204845.562; apg.altitude=      16279180.881
we (d/s,r/s)=      .00417807      .00007292

> sysacc flag = 1
> gravity flag = 10
> atd option = LULH attitude unchanged
```

# Gravity Model Selections

- Gravity flag: gflag
  - 0 g is fixed as given by [gx gy gz] (flat earth)
  - 10 g at bj.cm is defined by syspos (spherical earth)
  - 11 g at bj.cm is defined by bj.pos.eci
  - 12 same as #11 plus gravity gradient torque on bj
  - 20 g at bj.cm with J2 is defined by syspos (oblate earth)
  - 21 g at bj.cm with J2 is defined by bj.pos.eci
  - 22 same as #21 plus gravity gradient torque on bj
  - 30 g at bj.cm with J2, J3 and J4 is defined by syspos (oblate earth)
  - 31 g at bj.cm with J2, J3 and J4 is defined by bj.pos.eci
  - 32 same as #31 plus gravity gradient torque on bj

# Gravity Menu Commands

- Type 'spos' to edit orbit position in eci coordinates
- Type 'svel' to edit total velocity in eci coordinates
- Type 'grav' to edit gravitational acceleration, [gx, gy, gz]
- Type 'semi' to edit semimajor axis
- Type 'ecc' to edit eccentricity, ... and so forth
- Type 'perm' to edit orbit period in minutes
- Type 'sflag' to run simulation in prescribed(spos,svel) mode or in force determined(spos,svel) mode
- Type 'gflag' to select the gravity model for the simulation
- Type 'help' to get definitions of data and commands
- Type 'x' to exit menu
- Buildx automatically updates all orbit parameters when one of them is altered, i.e. changing 'perm' results in a new (spos, svel, ephemeris) ...etc.

# Dynamics Input

- Need input data to xsv01.dll to actuate the vehicle dynamics during run time
- Type 'input' from Model Menus to open the input menu to select data
- Use 'newlist' to get a suggested list for the current model
- Use 'add' and 'rem' command to modify current input list (udata)
- SV1simc input list is as follows:

```
Udata list:
```

```
1) whltq,1      | 2) whltq,2      | 3) whltq,3
4) whltq,4      | 5) xf,1         | 6) xf,2
7) xf,3         | 8) xf,4         | 9) xf,5
10) xf,6
```

- whltq, 1:4= four rwa torque
- xf,1:6 = six jet on/off signals

# Input Menu Commands

- Type 'add' to add new variables to the end of udata list
- Type 'add<j>' to insert new variables at udata(j)
- Type 'rem' to remove a group of variables
- Type 'rem<j>' to remove udata(j)
- Type 'chg<j>' to change udata(j)
- Type 'len' to see ordinal position of udata and their length
- Type 'x' to exit udata menu
  
- A variable selection menu appears on commands {add, chg}
- Type 'sel<j>' to select var(j) to add or chg
- Type 'x' to return to udata menu

- Procedure to define input signals for SV1simc:
  1. Type 'add' from Input Menu and see an Input Selection Menu
  2. Type 'sel17' for 'whltq' variable
  3. Reply the prompt with '1, 4' to select htqax1:4
  4. Type 'sel22' for 'xf' variable
  5. Reply the prompt with '1, 6' to select xf1:6
  6. Type 'x' to return to Input Menu
  7. Type 'x' to exit Input Menu

# Dynamics Output

- Need output motion signals from the dynamics engine to drive control system during run time
- Type 'output' from Model Menus to open the output menu to select signals
- Use 'newlist' to get a suggested list for the current model
- Use 'add' and 'rem' command to modify current output list (ydata)

```
Ydata list:
```

```
1> WREL,1          | 2> B2OSML,1
```

- wrel, 1 = bus angular rate in b1 frame
- b2osml, 1= small angle b1.attitude\_err wrt LVLH frame

# Output Menu Commands

- Type 'add' to add new variables to the end of ydata list
- Type 'add<j>' to insert new variables at ydata(j)
- Type 'rem' to remove a group of variables
- Type 'rem<j>' to remove ydata(j)
- Type 'chg<j>' to change ydata(j)
- Type 'len' to see ordinal position of udata and their length
- Type 'x' to exit ydata menu
  
- A variable selection menu appears on commands {add, chg}
- Type 'sel<j>' to select var(j) to add or chg
- Type 'x' to return to ydata menu



- Procedure to define output signals for SV1simc:
  1. Type 'add' from Output Menu and see an Output Selection Menu
  2. Type 'sel65' for 'wrel' variable
  3. Reply with '1, 1' to select wrel1
  4. Type 'sel3' for 'b2osml' variable
  5. Reply with '1, 1' to select b2osml1
  6. Type 'x' to return to Input Menu
  7. Type 'x' to exit Input Menu

# Plot Data

- Sample selected data from the dynamics engine to plotfile during run time
- Type 'plot' from Model Menus to open the Plot Menu to select plot data
- Use 'newlist' to get a suggested list for the current model
- Use 'add' and 'rem' command to modify current plot data list (odata)
- SV1simc plot list is as follows:

## Odata list:

```
1> QUAT,1           | 2> WREL,1         | 3> whlspd,1
4> whlspd,2        | 5> whlspd,3      | 6> whlspd,4
7> whltq,1         | 8> whltq,2       | 9> whltq,3
10> whltq,4        |11> syshmom       |12> SYSPOS
13> SYSUEL         |14> SYSACC        |15> B20123,1
16> syshb1
```

- quat, 1= b1.attitude\_quaternion in eci frame
- wrel, 1= bus angular rate in b1 frame ... etc.
- syshb1= system angular momentum in b1 frame

# Plot Menu Commands

- Type 'add' to add new variables to the end of odata list
- Type 'add<j>' to insert new variables at odata(j)
- Type 'rem' to remove a group of variables
- Type 'rem<j>' to remove odata(j)
- Type 'chg<j>' to change odata(j)
- Type 'len' to see ordinal position of udata and their length
- Type 'x' to exit odata menu
  
- a variable selection menu appears on commands {add, chg}
- Type 'sel<j>' to select var(j) to add or chg
- Type 'x' to return to odata menu

- Procedure to define Plot Data:
  1. Similar to those given for Input and Output data selection
  2. quat, 1= b1.attitude\_quaternion in eci frame
  3. wrel, 1= b1.angular rate ... etc.
  4. syshb1= system angular momentum in b1 frame

# Simplot

- Need to construct simplot1.m to view sim results in Matlab, then type 'simplot' from Model Menus page (page 12) or Plot Menu (page 43)
- All plot data were selected in Plot Menu
- A. steps from simPlot Menu:
  1. Type 'add' to add figures and respond with '4' to create 4 figures
  2. Type 'title1' to set figure (1) title: i.e. reply with 'system'
  3. for 'title2' and 'title3' commands, respond with 'bus', 'wspd' and 'wtq' respectively
  4. Type 'vars1' to define variables to be plotted in fig 1. this opens the plot variables page
- B. steps from vars menu:
  1. Type 'addv11' and reply with 4 to add 4 variables starting with the variable(11), syshmom
  2. Type 'addv16' and reply with 1 to add 'syshb1' to the variable list
  3. Type 'addp' and respond with '1,5' to create five subplots for figure(1)
  4. Type 'format' and respond with '3,2' to plot 6 subplots in 3 rows and 2 columns format
  5. Type 'x' to go back to simPlot Menu
- Repeat steps A.3 and all B steps with proper indexing to define subplots of other figures for SV1simc (i.e. 'bus', 'wspd' and 'wtq')
- Final steps from simPlot Menu:
  1. Type 'save' and reply with 'simplot1.txt' to save simplot data to simplot1.txt
  2. Type 'make' to create simplot1.m, see completion message
  3. Type 'x' to exit simPlot Menu. Simplot1.m is ready.

# Save Model Data

- Need to save current data to a model file
- Type 'save' from Model Menu (page 12) and complete the save dialog as follows

```
[body   force   torque  pmkr   dmkr   input  output  plot    1
[simplot flex   jnt   cnx  wheel accel  gyro   grav   sunPos  1
[times  vmass   pmass  discr  ode   switch states sumry  units 1
[compute cn    tree(f/t/p/d)  cgen   help   save   x    1
> save

Commands:
1. save model data to sv1sim.txt
2. save model data to another file
3. Cancel save
Select 1:3? 1

model data has been saved to sv1sim.txt
```

- On hitting return, current model data would have been saved to SV1simc.txt
- Try option 2

# Exit Buildx

- 3 ways to exit Buildx:
  - go to Model Menus or Main Menu and type 'q' <return>
  - go to Main Menu and type 'x'
  - Click the 'x' on top right corner of the Buildx window
- note: Buildx.exe does not save model data automatically. see save procedure on page 47

# Q & A

- Can one add and delete bodies, wheels and forces?
  - yes if you have enterprise license, and no if you have a project license
- Can jet forces placement and alignment be specified like in real vehicles?
  - Yes, one must in every case match the jet controller with the torque characteristics of the jets
- Are all Project licenses strictly for object count {1, 4, 8}?
  - no, for example a Project license for a vehicle with 4 CMG's has an object count of {5, 4, 8} and a unique parent-child relation between bodies, wheels and forces
- How to setup SV1simc as a 3 wheel system under a Project license?
  - go to xsv.wheel menu and set whl(4).type=3, whl(4).wspd=0
  - edit whlj.axis, whlj.inr, whlj.wspd for j=1:3 as necessary
- How to setup satsim with < 8 jets under a Project license?
  - as an example, let's disable jet(7:8):  
go to xsv.forcemenu and set frc(7:8).type=1 and not include these in xsv.input list (udata)



- How can one see all the available input, output and plot variables when choosing them from udata, ydata and odata menus?
  - all available variable list is shown when one types 'add' command from the menu
  - Type 'defj' to get the definition of variable(j) in that list
  - Type 'selj' from the add menu to select variable(j) to the list
- How does one change the plot data sample period?
  - Type 'plotdt' from the Main Menu or from the times menu to do that
- Why are there 'dt' and other time specification in the times menu?
  - those time specifications are not used for the Simulink applications, they are for the Fortran and C implementation of xsv01 engine


# Part II Topics

- Xsv01.exe
- How Control.dll Works
- User\_code.c
- Vehdata.h
- Utilc.lib subroutines
- Acsc.lib subroutines
- Control System
- Example1
- Example2
- Adjustable Simulation Parameters
- Exercises
- Simulation Notes
- Summary

# XSV01.exe

- Xsv01.exe is the main program. It comes with the SV1simc package. Its functions are to:
  - Read data from model file to initialize the simulation database
  - Integrate numerically the motion equations required by the model file while passing motion signals to and receiving actuation signals from the control system represented by control.dll.
- Control.dll is the application specific control system that user provides to cause the vehicle motion respond in a desired manner.

# Xsv01.exe Dataflow



- Model\_file: defines all parameters of the vehicle for the simulation
  - Summary\_file: records all the model parameters and initial condition of an xsv01.exe run
  - Plot\_file: a file of sampled plot data recorded during a simulation
  - Message\_file: messages from xsv01.exe during a run
- > Part I has already described how to build the model file for sv1simc.
- > Part II begins next

# Part II Introduction

- The following charts show how to build a trial control.dll that has the framework of the control system needed for the application.
- Two parts need to be built: control subroutines and header file
- At a minimum, we would use Buildx.Codegen Menu to construct 5 key control subroutines and their header files.
- Any discrete/analog process in the control system counts as an additional control subroutine that Codegen must account for.
- Special control subroutine names cause Codegen to insert practical details into those routines
- Constants and utility routines inserted by Codegen in the trial control.dll need be replaced with those based on analysis and application specific algorithms later.
- A functional control.dll should be obtained after a few iterations of running it with xsv01.exe and correcting errors.
- From that point on, user can expand the size and details of the control subroutines to satisfy their simulation needs.


# How Control.dll Works

- It calls five subroutines: `c_init`, `c_in`, `c_discret`, `c_analog`, `c_out`
- The purpose and frequency of call to these subroutines are shown on the following pages.
- The header file used by these subroutines are defined in the `vehdata.h`
- Files in the package that help in the construction of `control.dll` are:

Files in the package	Description
<code>Control.obj</code>	Object code of <code>control.c</code>
<code>Utilc.lib</code>	Matrix-vector math utility routines
<code>Utilc.h</code>	Utilc subroutine call prototypes
<code>Acs_c.lib</code>	Attitude control system subroutines
<code>Acs_c.h</code>	Acs_c subroutine call prototypes

# Primary Control.dll Subroutines

Control.dll





# Primary C-Routines

subroutine	Call frequency	Function
C_init	Once at start of simulation	Initialize control related parameters
C_in*	At top of every derivative calculation	Read the motion signals from the plant dynamics
C_discret	At top of every derivative calculation	Execute all discrete events at discrete times
C_analog	At every derivative calculation	Execute all analog computations for signal processing and control
C_out*	At end of every derivative calculation	Send actuation signals back to the plant dynamics

# Building Control.dll

- A Short description of how to build control.dll:
  1. Go through a 'Codegen' procedure given next using Buildx.exe to generate a user\_code.c.tmp and the related header file vehdata.h.tmp. The former is a template of the five subroutines called by control.dll
  2. User would add details to user\_code.c.tmp and vehdata.h.tmp as required by the application.
  3. At the end of that process change user\_code.c.tmp to user\_code.c
  4. Likewise, change vehdata.h.tmp to vehdata.h
  5. Compile control.dll with the following CL command at DOS prompt
    - 'CL control.obj user\_code.c util.lib acsc.lib /LD'

# Codegen Procedure

- Purpose: generate user\_code.c.tmp, vehdata.h.tmp
- Given: vehicle model file from Part I

Preprocessing:

1. Go to Buildx >xsv > Model Menus
2. Use 'discrt' command to define discrete/analog processes : name and sample period (as necessary); period=0 => analog process
3. Use 'ode' command to define application specific 'ordinary differential equations': name, and state size (as necessary)
4. Use 'switch' command to define switches for events: switch name and simple switch function (as necessary)
5. Type 'cgen' to open the Codegen Menu

# SV1simc Discrete Processes

- For SV1simc, we defined 2 processes: `acs_rwa(discret)`, `acs_jet(discret)`
- This definition is done by using 'add', 'name' and 'period' commands

```
~ Discrete Process Menu ~
Nof discrete process: 2
Idx Name          Period      Start_t
=>  1 acs_rwa      .1000E+00  .0000E+00
    2 acs_jet      .1000E+01  .0000E+00
[ sel add rem copy idx name order period start x ]
>
```

- Need to save the new model data to `sv1simc.txt`
- Next, Go to Codegen Menu by typing 'cgen' from Model Menus
- Note: `acs_rwa` and `acs_jet` are two special discrete process names, because they cause Codegen to insert functional details in the generated code

# ACS\_C.lib Subroutines

- These are subroutines written for the examples, by that they need be replaced when configuration or mass property change from those given.

Subroutine	purpose	Examples
Get_acscmd	Compute ACS command signal to null attitude error	Sv1simc, arraysimc, cmg4simc
Get_6jettimes	Compute 6 jet on/off times to null attitude error command	Sv1simc, arraysimc
Get_hmgr6jettimes	Compute 6 jet on/off times to null system angular momentum	cmg4simc
Get_cmgtq	Compute CMG input torque to null attitude error	cmg4simc

# Special Names

- These special subroutine names when given to discrete processes cause functional codes to be generated for those .c.tmp routines

Process name	Purpose	Acs_c.lib routines invoked
acs_rwa	Generate RWA torque for ACS	Get_acscmd
acs_cmg	Generate CMG torque for ACS	Get_acscmd Get_cmgtq
acs_jet	Compute jet on/off times for ACS	Get_acscmd Get_6jettimes
hmgr_jet	Compute jet on/off times to null system angular momentum, syshb1	Get_hmtr6jettimes

# Codegen Menu

- Data on this page needs be edited to assist in code generation

```
System Graph:
b1<B>+-w[1,2,3,4]

      Size      Hinges
sa      :      0      0  0
cmg     :      0      0  0  0  0  0
rwa     :      4
jets    :      6
gyros   :      3
cmdx_dt: .100000E+00
gyro_dt: .100000E+00
jet_dt : .100000E+01
rwa_dt : .100000E+00

generate:
cmdx code: no
gyro code: yes
rwa code: no

Commands:
[sa cmg rwa jets gyros dt cmdxC gyroC rwaC codeGen ]
[editc edith read save help x ]
```

- Type 'sa' to define number of arrays (max=2) and the driver hinges (bodies)
- Type 'cmg' to define number of CMG's and the rotor platform bodies
- Type 'rwa' to define number of reaction wheels
- Type 'jets' to define number of jets
- Type 'gyros' to define number of gyros
- Type 'dt' to define the sample period of 4 discrete processes
- Type 'codegen' to generate components of user\_code.c.tmp and vehdata.h.tmp
- Type 'gyroc' to toggle 'generate gyro code' flag
- Type 'rwac' to toggle 'generate rwa code' flag
- Type 'cmdxc' to toggle 'generate cmdx code' flag
- Type 'editc' to view and edit all \*.c.tmp codes
- Type 'edith' to view and edit all \*.h.tmp codes
- Type 'save' to save codegen data to 'codegendata.txt'
- Type 'read' to read codegen data from 'codegendata.txt'
- Type 'help' to get definition of menu data and commands
- Type 'x' to exit menu



- Let's concentrate on the two discrete processes that was defined for sv1sim1c.txt
- Next, type 'codegen' to generate the .c.tmp and .h.tmp files needed to build user\_code.c.tmp and vehdata.h.tmp

```
> codegen
created ctrl_input.h.tmp
created ctrl_output.h.tmp
created global_vars.h.tmp
created c_in.c.tmp
created c_init.c.tmp
created c_discret.h.tmp
created c_discret.c.tmp
created acs_rwa.h.tmp
created acs_jet.h.tmp
pgain & vgain for rwa control? 10,200
start and end times of asc_rwa? 2000 0
created acs_rwa.c.tmp
start and end times of asc_jet? 0 2000
created acs_jet.c.tmp
created c_gyro.c.tmp
created c_analog.c.tmp
created c_out.c.tmp
```

- You will be prompted for some gain and timing information in this dialog. Supply as appropriate.
- End time less than Start time means execute the code for 't > Start time'
- Start time= End time= 0 means ignore time window code request

- Next, type 'editc' to view user\_code.c.tmp components and to assemble user\_code.c.tmp

```
                                Edit Cpp Files Menu

1. c_in.c.tmp
2. c_init.c.tmp
3. c_discret.c.tmp
4. acs_rwa.c.tmp
5. acs_jet.c.tmp
6. c_analog.c.tmp
7. c_out.c.tmp

Commands:
[ edit  add  name  rem  reset  assemble  help  x ]

>> _
```

1. One can view and edit each one of the \*.c.tmp code using the 'editj' command where j is the index preceding the displayed code.
  2. Type 'assemble' to assemble all displayed \*.c.tmp subroutines into user\_code.c.tmp. The latter becomes item 8 in the above list.
  3. Type 'edit8' in this case to view user\_code.c.tmp
- Just edit user\_code.c.tmp from here (i.e. 'edit8') until it is acceptably complete
  - Type 'Accept' to copy user\_code.c.tmp to user\_code.c, and exit (see Appendix A)

- Type 'edith' to view the generated vehdata.h.tmp components and to assemble vehdata.h.tmp

```
                                Edit .h Files Menu

1. ctrl_input.h.tmp
2. ctrl_output.h.tmp
3. global_vars.h.tmp
4. c_discret.h.tmp
5. acs_rwa.h.tmp
6. acs_jet.h.tmp

Commands:
[ Edit  Add  Name  Rem  Reset  Assemble  Help  x]

>>
```

1. One can view and edit each one of the \*.h.tmp code using the 'editj' command where j is the index preceding the displayed code.
  2. Type 'assemble' to assemble all displayed \*.h.tmp subroutines into vehdata.h.tmp. The latter becomes item 7 in the above list.
  3. Type 'edit7' in this case to view vehdata.h.tmp
- Just edit vehdata.h.tmp from here on (i.e. 'edit7') until it is acceptably complete
  - Type 'Accept' to copy vehdata.h.tmp to vehdata.h, and exit (see Appendix B)

# Compile Control.dll

- After obtaining user\_code.c and vehdata.h files, exit buildx.exe
- Type 'mkcontrolc.bat' to compile control.dll
- Fix any compilation error that appear in user\_code.c or in vehdata.h
- The xsv01.exe simulation is now ready to run

# Example1

- This example shows the LVLH control with jet for  $t < 2000$  and with rwa for  $t \geq 2000$ .
- The attitude command signal is generated from true b1 angular rate (w1) and xsv01.exe provided LVLH attitude error (b2osml1)
- Buildx procedure:
  - start Buildx and go to body menu
  - set 'wrel1' to [.1, .2, .3]degrees
  - from gravity menu, set [ecc,incl,period]=[0.,35 deg, 100 min]
  - save model data to SV1simc.txt from Model Menus

# Run xsv01.exe

- Click c:\SV1simc\xsv01.bat and see a running display as follows.

```
C:\sv1simc>.\xsv01
xsv01> t= .0000000E+00
xsv01> tuna> tunaIc+
          tPrint,tPlot,dtPrnt,dtPlot=
          .50000E+02 .20000E+01 .50000E+02 .20000E+01
simMethod= RK2
tuna> tuna_rk2(*),t= .0000000E+00
h= .1000000E-01; tf= .3000000E+04 <RK2>
model file= sv1simc.txt
plot file = z.1
summary   = sim1_summary.txt
xsv01> t= .5000000E+02
xsv01> t= .1000000E+03
xsv01> t= .1500000E+03
xsv01> t= .2000000E+03
xsv01> t= .2500000E+03
```


...

```
xsv01> t= .2900000E+04
xsv01> t= .2950000E+04
xsv01> t= .3000000E+04
C:\sv1simc>
```

# View Sim Results

- Type 'load z.1' from Matlab window to read in sim result
- Type 'simplot1(z)' to view result
  - simplot1.m is a script that was constructed using Buildx.exe (see page 46)


# Fig.1 System Motion



- orbit:  
35 deg incl  
ecc=.001  
6000 sec orbit period  
gravity: gflag=10
- s.s. sysmom:  
constant system angular  
momentum in eci coord  
hmag  $\sim 0.6$  ft-lb-s
- syshb1:  
sysmom in b1 coord




# Fig.2 B1 Motion



- acs:  
b1 attitude is LVLH  
b201231=rpy  $\sim 0$   
for  $t > 2000$
- ss b1 angular rate  $\sim$   
[0 -orbrate 0] d/s
- sat3w orbrate= .03 d/s

# Fig.3 Wheel Speed



- wheel speeds are low due to jet LVLH ACS for  $t < 2000$  that kept syshb1 to near zero (Fig. 1)

# Comment

- This example showed that the vehicle inertial angular momentum is reduced from 7.75 ft-lb-s to near zero (0.6) shortly after enabling jets at start. The momentum remained so for the rest of the simulation
- The LVLH attitude error is under 0.3 deg for  $t=[0:2000]$  with jet ACS and stayed near zero thereafter because of RWA ACS
- The steady state body rate is the orbit rate as controlled by the jets and the RWA
- The wheel speed is low because of the size of the system angular momentum.

# Example2

- Model file for this example is identical to the one used in Example1.
- The change is to replace the true rate 'w1' with gyro derived 'gyr\_rate' in computing the rate error in acs\_rwa.c and acs\_jet.c subroutines in user\_code.c.
- Procedure:
  1. Make the above changes in user\_code.c
  2. Type 'mkcontrolc.bat' to compile control.dll
  3. Type 'xsv01.exe' to run the simulation
  4. View sim results in Matlab using simplot1.m
- Comment:
  - The three charts, System Motion, B1 Motion, and Wheel Speed response, from this example are nearly identical to those obtained from Example1

# Adjustable Sim Parameters

- Dt: simulation integration step size
  - plotDt: plot data sample period
  - printDt: time display sample period
  - T: simulation period
  - Method: Integration method, RK2 or RK4
- 
- Edit procedure:
    1. Go to Main menu
    2. Use 'stepsize', 'dtplot', 'printdt', 'endtime', 'method' commands to change the
    3. sim parameters
    4. Type 'save!' to save changes to siminputfile
    5. Reply with 'sim1files.txt'
    6. exit buildx

# Exercises

actions	parameters	reference
change mass property	mass, inr, svec, dvec	pages:15-20
change initial condition	ang,wrel,wrelax, dcm0	pages:15-17
change orbit	ephemeris, orbit period	pages:33-36
add /remove bodies*		pages:15-17
add /remove wheels*		pages:25-27
add/remove forces*		pages:29-32
modify input (udata)		pages:37-39
modify output (ydata)		pages:40-42
modify plot (odata)		pages:43-45
modify simplot1.m		page:46

\* Not for project licenses

actions	changes	control system config
design your own rwa controller	<ul style="list-style-type: none"> <li>•may need new ydata</li> <li>•may need less than 4 wheels</li> </ul>	<ul style="list-style-type: none"> <li>•likely identical to SV1simc</li> <li>•adjust i/o mux/dmux</li> </ul>
design your own jet controller	<ul style="list-style-type: none"> <li>•may need new ydata</li> <li>•may need nof jets other than 8</li> </ul>	<ul style="list-style-type: none"> <li>•likely identical to SV1simc</li> <li>•adjust i/o mux/dmux</li> </ul>

# Simulation Notes

Subject	SV1simc	comments
gforces	comment applies to SV1simc	gravity forces are auto-computed by sim engine for all bj in system
jet forces	force locations and vectors were selected for SV1simc to cause each jet torque to align with a particular b1.xyz axes to get a simple jet controller	generally jets are not placed ideally as in SV1simc because of other design considerations. as such, associated jet controller can be complex
wheels	SV1simc chose a 4 corner pyramid configuration	pyramid base to height ratio can vary and the center axis of pyramid need not be along any particular b1.xyz axis
geometry	SV1simc is a gyrostat and b1.cm is same as system.cm regardless of how b1.svec is defined	position and orientation of body parts are defined by their dvec, svec ,dcm0 and joint coordinates



Subject	SV1simc	comments
b1.dcm0	comment applies here also	Dcm0 of b1 is the initial LVLH attitude of the vehicle
mass, inertia	comment does not apply to SV1simc since it has only one regular body	mass and inertia can be set to zero for non-terminal bodies to represent ideal massless joints
sunb1,nadirb1	sun vector and nadir vector in b1 frame were not used in SV1simc control system	these two ydata are available for for sun sensor and earth sensor modeling
b2osml	this small angle LVLH attitude error of b1 computed by the sim engine is the rpy signal in the examples meaning (roll,pitch, yaw) angles.	this ydata signal is available as a functional convenience to ACS analysis. A more realistic rpy signal needs be built from sunb1 and nadirb1
syshb1	this is the system angular momentum in b1 frame, not used in SV1simc	this ydata signal is available as a functional convenience to momentum mgmt design

# Summary

- Two examples given here show that xsv01.exe with a properly constructed control.dll can simulate the dynamics of a vehicle with jet and RWA ACS in maintaining LVLH attitude.
- The value of SV1simc is that its mass property can be changed to fit the vehicle of interest . It requires that a C/C++ compiler be installed on the PC to compile control.dll. With the Buildx editor, one can define a variety of Dynamics Input/Output signals to design and test his application specific control system. More importantly, it can be very effective in the design of any single body vehicle, its operations and control system.

# Appendix A

## User\_code.c

- `// This user_code.c is generated by Buildx.exe`
- `//`
- `// These subroutines manage the data in:`
- `// vehdata.h variables & constants used by`
- `// control.dll`
- `// utilc.h have the prototypes of matrix-vector`
- `// subroutines used in the generated code`
- `#include <stdio.h>`
- `#include <math.h>`
- `#include "vehdata.h"`
- `#include "utilc.h"`
- `// Control Input Mapping: x->local data`
- `void c_in(double *x,double *T){`
- `equal( w1, &x[0],3 );`
- `equal( b2osml1,&x[3],3 );`
- `equal( gyr_ang,&x[6],3 );`
- `t= T[0];`
- `}`

- // initialization procedure.....
- void c\_init(){
- worb[0]= 0.;
- worb[1]= -.523599E-03; //(rps),temporary
- worb[2]= 0.;
- }
- 
- // c\_discret procedure.....
- void c\_discret(double \*T){
- int jet; // jet index
- 
- discrete(acs\_rwa, T, &acs\_rwa\_t);
- discrete(acs\_jet, T, &acs\_jet\_t);
- discrete( c\_gyro, T, &gyr\_t );
- for (jet=0; jet < 6; jet++){
- xf[jet]=0;
- if( T[0] > jet\_on[jet] & T[0] <= jet\_off[jet] )
- xf[jet]=1;
- }
- }

- void acs\_rwa( double \*ts ){
- //This procedure is called at time= \*ts
- double G[12]={ .433013E+00, .433013E+00,-.433013E+00,-.433013E+00,
- -.433013E+00, .433013E+00, .433013E+00,-.433013E+00,
- .433013E+00, .433013E+00, .433013E+00, .433013E+00};
- double cmd[3];
- double gain[2]={ .100000E+02, .200000E+03}; //temporary
- 
- double sc=-1 ;
- 
- if(\*ts > .200000E+04 ){
- subv( worb, gyr\_rate, tempv );
- get\_acscmd( gain, b2osml1, tempv, cmd); //see acsc.h
- mtxmv( G, cmd, wtq, 4, 3); //wtq=G\*cmd
- 
- mtxsv( &sc, wtq, wtq, 4 ); //wtq=-wtq
- }
- 
- \*ts= \*ts + acs\_rwa\_dt ;
- }
-

- void acs\_jet( double \*ts ){
- //This procedure is called at time= \*ts
- double cmd[3];
- double gain[2]={10,200}; //temporary
- double hjet= .300000E+01; //jet impulse/sec, temporary
- 
- if(\*ts <= .200000E+04){
- subv( worb, gyr\_rate, tempv );
- get\_acscmd( gain, b2osml1, tempv, cmd); //see acsc.h
- get\_6jettimes(ts, cmd, hjet, jet\_on, jet\_off ); /\*TEMP CODE\*
- }
- 
- \*ts= \*ts + acs\_jet\_dt ;
- }
- 
- // c\_gyro procedure.....
- void c\_gyro(double \*ts){
- double tempv[3];
- 
- subx( gyr\_ang, gyr\_ang\_prev, tempv, 3) ;
- mtxs( &gyr\_freq, tempv, gyr\_rate, 3) ;
- equal( gyr\_ang\_prev, gyr\_ang, 3) ;
- \*ts= \*ts + gyr\_dt ;
- }

- `// Control analog procedure...`
- `void c_analog(double *T){`
- 
- `}`
- 
- 
- `// Control Output Mapping: u->dx/dt`
- `void c_out(double *T,double *u){`
- 
- `equal( &u[0],wtq,4 );`
- `equal( &u[4],xf,6 );`
- `}`
- 
-

# Appendix B

## Vehdata.h

```
/* control data: Udata */
double whltq1; /* wheel( 1) torque*/
double whltq2; /* wheel( 2) torque*/
double whltq3; /* wheel( 3) torque*/
double whltq4; /* wheel( 4) torque*/
double xf1; /* external force on body( 1)*/
double xf2; /* external force on body( 2)*/
double xf3; /* external force on body( 3)*/
double xf4; /* external force on body( 4)*/
double xf5; /* external force on body( 5)*/
double xf6; /* external force on body( 6)*/
double jet_on[100] ; /* jet start time */
double jet_off[100] ; /* jet end time */
double xf[20] ; /* jet [1/0] array */
double worb[3] ; /* orb rate in b1 frame */
double wtq[5] ; /* wheel torque(max 5) */
double cmgtq[5] ; /* cmg.input.tq(max 5) */
double cmg_ang[5] ; /* cmg.input.ang(max 5) */
double cmg_rate[5] ; /* cmg.input.rate(max 5)*/
int current_jet ; /* jet being processed */
```



- /\* control data: Ydata \*/
- double w1[3]; /\* Body( 1) ANG RATE IN Body(1) FRAME\*/
- double b2osml1[3]; /\* Ref body to orbit attitude SMALL(XYZ) angles\*/
- double gyr\_ang\_x[3]; /\* GYRO cumulative angles\*/
- 
- /\* Global variables & constants \*/
- double tempv[3],tempw[3];
- double pi= 3.14159265358979 ;
- double twopi= 6.28318530717959 ;
- double d2r= 0.01745329251994 ;
- double r2d= 57.29577951308232 ;
- double t ;
- 
- void turn\_jet\_off( double \* ) ;
- 
- // c\_gyro: output delta angle per gyro per acs\_dt
- void c\_gyro(double \*);
- double gyr\_dt = .10000E+00 ;
- double gyr\_freq= .10000E+02 ;
- double gyr\_ang[3] ;
- double gyr\_ang\_prev[3] ;
- double gyr\_rate[3] ;
- double gyr\_t = 0. ;

- `void acs_rwa( double * );`
- `double acs_rwa_data[10];`
- `double acs_rwa_t= .000000E+00;`
- `double acs_rwa_dt= .100000E+00;`
- 
- `void acs_jet( double * );`
- `double acs_jet_data[10];`
- `double acs_jet_t= .000000E+00;`
- `double acs_jet_dt= .100000E+01;`
-

# Appendix C

## Utilc.h

- `void addmtv( double *, double *, double *, double * );`
- `void addmv( double *, double *, double *, double * );`
- `void addsv ( double *, double *, double *, double * );`
- `void addsx ( double *, double *, double *, double *, int );`
- `void addv( double *, double *, double * );`
- `void addx( double *, double *, double *, int );`
- `void cross( double *, double *, double * );`
- `double cswitch ( int, double *, double *, double * );`
- `void dc2q( double *, double * );`
- `void dcsmall( double *, double * );`
- `void discrete( void (*)(double *), double *, double * );`
- `double dot( double *, double * );`
- `double dotx( double *, double *, int n );`
- `void equal( double *, double *, int );`

- void mtxsv( double \*, double \*, double \*, int );
- void mtxmtv( double \*, double \*, double \*, int, int );
- void mtxmv( double \*, double \*, double \*, int, int );
- void multmm( double \*, double \*, double \* );
- void multmtv( double \*, double \*, double \* );
- void multmv( double \*, double \*, double \* );
- void multsv( double \*, double \*, double \* );
- void null( double \*, int );
- void qdot( double \*, double \*, double \* );
- void qinv( double \*, double \* );
- void qiqmult( double \*, double \*, double \* );
- void qmult( double \*, double \*, double \* );
- void q2dc( double \*, double \* );
- void submtv( double \*, double \*, double \*, double \* );
- void submv( double \*, double \*, double \*, double \* );
- void subv( double \*, double \*, double \* );
- double unitvec( double \*, double \* );
- void xyzrot ( int \*, double \*, double \*, double \* );